

Shoal – Aqua Silk

This pattern is printed on 100% Silk wallcovering. All production is done per order and takes up to 5 weeks to ship. Please be sure to order a sample before purchasing rolls.

100% Silk wallcovering is a delicate, hand-woven, earth-friendly silk backed with chemical-free paper and printed with water-based latex inks. This material is suitable for residential and low-traffic commercial locations.



Vertical Repeat	31.5"
Horizontal Repeat	33" **Please note this pattern is a half drop repeat
Roll Width	33"
Roll Length	15' when ordered in multiples comes printed continuously as double or triple rolls

Pricing	Sold by the roll
Selvage	1" paper comes untrimmed
Sample Size	8.5" x 11" **If you are unsure of color please order a sample before purchasing.

Wallpaper Type	100% Silk
Material	100% Silk backed with chemical free paper
Print Method	Digital latex water-based ink
Lead Time	3-5 weeks **Rush Service subject to availability. Rush fee does not include expedited shipping.

Care	Not Wipeable. When cleaning silk wallpaper, the best approach is to lightly dust it or use a vacuum cleaner with a soft brush attachment. Avoid using magic eraser sponges, any form of scrubbing, or moisture-based cleaning products, as they will damage the fibers and potentially leave unsightly watermarks. If you need to remove small stains, use a cotton swab and a mild soap and water cleaning solution, taking care to dab gently and not to rub or scrub the wallpaper. Never use solvents or alcohol.
Fire Rating	Class A (ASTM E84)
Color & Scale	We always strive for color accuracy but please note that colors shown on the website are a representation only. Please refer to the actual product sample. **Also due to varying ink/print systems wallpapers and fabrics of the same pattern are not always an exact match in color or scale.
Made In	USA

8' tall x 9' long wall
pictured below
in Shoal —
Aqua Silk



How to Measure the Amount of Paper to Order

**We always recommend confirming quantities with your wallpaper installer prior to ordering.

We recommend measuring with a yardstick or steel tape measure. Make your measurements in feet and round off to the next half foot or foot. Measure the wall height from the floor to the ceiling, excluding any baseboards or moldings. Then measure the length of the wall without deducting for windows or doors (this will leave you extra wallpaper in case you may need it). Multiply the two measurements to find the surface area of the wall.

Single rolls of this paper are 15 feet long and 33 inches wide. 1 roll covers about 40 square feet. To find the number of rolls needed to cover your wall, multiply the height and the width of the wall by rounding up each length to the nearest foot. Then divide by 40.

Example: For a wall that is 10 feet 6 inches high by 9 feet 4 inches long. Round up and multiply 11 feet by 10 feet to get 110 square feet. Divide 110 by 40 and you will get 2.75. In this case you will need 4 rolls.

If the number divides out to be .5 or above, you will need to add one more roll on to be safe. If you were to get 2.4, 3 rolls would be enough, but if you get 2.5 to 3.4, you will need 4 rolls.

Please feel free to contact us anytime for assistance in finalizing your calculation.

Silk Wallcovering Installation Guide

Eskayel highly recommends consultation with a professional paperhanger prior to installation.

These instructions are for our SILK wallcovering only.

Wall Preparation

The walls to be covered must be properly prepared to insure that the wallpaper will adhere to the wall surface. Even the strongest adhesive can only work when the wall surface is clean and properly prepared.

Building & Material Conditions

- The building must be weather-tight with HVAC settings (including pressure, temperature and relative humidity) the same as those of an occupied building for three days prior to, throughout installation and three days after installation.
- The walls must be structurally sound including elimination of sources of moisture accumulation into the wall or wall cavity.
- The wallcovering must be in a clean and dry condition and must be stored at normal occupied building temperature and humidity for at least three days prior to installation.
- All adhesives and primers must be new, good quality, commercial grade materials, which have not been contaminated.

Preparation

- Before you cut and hang, please be sure you have:
- The correct wallcovering and the correct amount of wallcovering to finish the job.
- Inspect the wallcovering carefully to ensure it is free of defects: If no defect is evident before installation, the material should be inspected after three (3) strips are installed. If any defect is evident at this time (or at any point in the installation) no additional material should be hung. **NO CLAIMS WILL BE ALLOWED FOR MORE THAN (3) STRIPS ON THE WALL.** All claims must be made within 30 days of the invoice date. No labor claims will be allowed at any time.

Adhesive

- We recommend using a clay adhesive.
- Apply the paste to the back of the paper, which will become flexible and easy to hang.
- Do not add excessive water to the paste as it may cause the backing paper to pull away from the front.

Trimming

- Please create your own precision edge on your work table or by making a double cut on the wall for the finest seam possible.
- Trim edges with a VERY sharp razor blade. **CHANGE YOUR BLADES OFTEN.**

Installation

- Plumb wall for first strip.
- Cut strips and allow extra material at the top and bottom for trimming. Hang strips in the same sequence as cut from master roll.
- After cutting the strips from two bolts, take a few minutes to shade the strips from light to dark to ensure the most even shading. The installer may reverse strips if they feel that it will produce the most even shading. Once you are satisfied with the shading from the first two bolts, cut and shade the balance of the rolls.
- Apply wallcovering to wall surface, smoothing out all bubbles with a soft brush or cloth.
- Do not use wooden or nylon seam roller as this can polish the surface.
- For vertical strand quality, smooth out bubbles in a direction parallel to the patterns, while paying attention to the fibers on the surface of the wallcoverings.

Important

- **DO NOT FOLD** this wallcovering while pasting or booking, as it is susceptible to potential wrinkling and creasing.
- Use a soft brush or cloth when hanging, so that you do not damage the face of the wallcovering.
- **DO NOT** allow paste or excessive water to stain the front of the wallcovering.
- Silk wallcoverings have a natural finish and may show some shade variation from strip to strip. As the wallcovering oxidizes, these variations should soften over time.
- Paste, trim and hang one strip at a time.
- Gently smooth the wallcovering using a plastic smoother in the direction of the fiber. Do not use a seam roller.